

# ZINGER®

## Quick Start Guide

---

Now that you have unpacked your Zinger, you can start riding in 4 quick and easy steps. Here's how:

**Step 1.** After unfolding the Zinger (see unpack guide), insert the basket and battery.

*Basket Insertion*



*Battery Insertion*



**Step 2.** Power up your unit by pressing the power button. The control arm will light up and indicate the speed level and battery life. The Zinger always turns on in the low speed setting.



# ZINGER®

## Quick Start Guide

---

**Step 3.** While sitting in the chair, gently lift both the left and right handles up to disengage the brakes. You will hear a click when the brakes are disengaged. Then, gently pull the trigger and push both left and right levers down to move forward. There are 3 speeds available for indoor/outdoor use that range up to 6 mph. To change the speed level, simply press and depress the speed button and the light will confirm the change (*See manual for speed setting usage guidelines*).



**Step 4.** To turn left or right, simply raise the left lever to turn left, and raise the right lever to turn right while keeping the opposite lever down. To brake or stop, simply raise both the levers up.



*More detailed information is available in your owner's manual and if you have any additional questions, our customer service department is available to you 9AM to 6PM M-F EST. 800-958-8324*